

Design Build Release for Construction (RFC) Plans Submission

Innovative Delivery

1. Place the plans in the *CST\Construction Plans\Current Plans* folder in ProjectWise setting the Document Type as follows.
Document Group: *Preliminary Engineering*
Document Category: *Design Plans*
Document Type: *Construction Plans*
Click on **OK**
2. Set the **Public Access** for all plans in the *CST\Construction Plans\Current Plans* folder.
 - a. Select all the files in the folder.
 - b. Right-click and select **Modify**.
 - c. Select the **GDOT Environment** tab.
 - d. Scroll down to **Public Access** and enter “1” for the value.
 - e. Click on **Apply** and then **Close**.
3. Set the **Sheet Types** for all sheets under the *CST\Construction Plans\Current Plans* folder.
 - a. Select all the same type files in the folder
 - b. Right-click and select **Modify**
 - c. Select the **GDOT Environment** tab.
 - d. Scroll down to **Sheet Type** and select the appropriate sheet type from the drop-down.
 - e. Click on **Apply** and then **Close**.
 - f. Continue until all sheet types are assigned to the plans.